




Line of Balance

Line of Balance (LOB^1) is a method of showing the repetitive work that may exist in a project as a single line on a graph. Unlike a Bar Chart, which shows the duration of a particular activity, a LOB Chart shows the rate at which the work that makes up all of the activities has to be undertaken to stay on schedule², the relationship of one trade or process to the subsequent trade or process is defined by the space between the lines. If one group is running behind schedule, it will impact on the following group and this is shown by the lines intersecting.



LOB is used on repetitive work such as constructing multiple dwelling units, when used on linear work such as roads and railways the technique is more accurately called Time/Location Charts or Chainage Charts which include 'blocks' to mark out chainages such as bridges and culverts that require substantial time to build and interrupt the general flow of work.





¹ The generic term for this type of chart is 'Elemental Trend Analysis'.

² Multiple-Activity Charts can be used to determine the rate of progress (or cycle times) used in the LOB chart, see: <u>http://www.mosaicprojects.com.au/WhitePapers/WP1025</u> Multi-Activity Charts.pdf



www.mosaicprojects.com.au




A Simple Example³

Let's look at a 100 segment pipeline project and the process of planning and scheduling a realistic, feasible, and profitable work plan.

For the 6 activity types we initially plan the following for a project with the same soil type:

Clearing, Survey, & Staking	5 man crew, 1 segment/day 100 days
Trenching	3 man crew, 1⁄4 segment/day 400 days
Placing Bedding select material	3 man crew, ½ segment/day 200 days
Laying Pipe and connecting joints	6 man crew, ½ segment/day 200 days
Hydraulic Testing of 1 segment	2 man crew, 4 segments/day 25 days
Backfill and Grading	4 man crew, 1/3 segment/day 300 days



Crew Interference: Stop & Wait

The Project will take almost 700 days due to completion of Bedding and Laying Pipe until all of the Trenching is done after 408 days and the start of testing delayed until the 383rd day with multiple crew interference.

Doesn't look so smart, does it; so what can we do?

- Of course we might balance the production rates so they are all equal, but that is rarely practical.
- Perhaps we can delay the start of a following crew until there is enough work for them to work without waiting for the prior crew to provide them work areas. We do not want to have activity-crews standing idle waiting for the next work area.

This could be achieved by delaying the start of trade crews to avoid overlapping prior crews so that they will not be waiting for the next segment's work area.


- The Bedding work is delayed 200 days so that it finishes just after the trenching finishes.
- The Testing work is delayed 375 days so it does not finish before Laying Pipe finishes.
- This is the Line-of-Balance or 'Linear Scheduling'.

³ First published: PM World Today – June 2011 (Vol. XIII, Issue VI) as part of a series on construction project scheduling by Earl Glenwright,



www.mosaicprojects.com.au





Continuous Crew Schedules

Where as we might have thought the project was going to take 110 days, at 11 days/segment, due to keeping the crews fully working once they start, it will take 684 days because the Backfill and Grading cannot start until the 1st segment is tested. Is this realistic? Probably not but that is what the Line-of-Balance process is.

If it is feasible for the various crews to work say 5, 20 segment sections and then leave the site until another segment is available, the project time can be reduced accordingly. The Line-of-Balance then would have a series of stair step offsets. Making those decisions is the job of the management team. Once the Bedding, Laying of Pipe, and Testing of the 1st segment to done, then the Backfill can begin and work continuously. And the project will complete 240 days earlier. By dividing the project into 5 20-segemnt stages for the Bedding, Laying Pipe, and Testing , each segment is completed sooner and the periods that the trench is open are reduced.

	Days	100	200	300	400	500	600	700
Segments	100	Layout ->/			///			
	80			n				
					Testing			
	60			-/////	- resting			
			ayingpipe	Ħ// /				
	40	Trench Bedding						
	20		/// <-Ва	ckfill & Grad	ing			
	0							

Crew work interrupted and delayed



www.mosaicprojects.com.au


This work is licensed under a <u>Creative Commons Attribution 3.0 Unported License</u>. For more White Papers see: <u>http://www.mosaicprojects.com.au/WhitePapers.html</u>



From this starting point, a contractor after looking at the above Line-of-Balance chart would instinctively look at reducing the time of the Trenching. Perhaps 2 trenching crews can be mobilized thereby reducing the trenching time from 400 to 200 days. That's worth consideration. If Trenching is reduced to 200 days, then Bedding and Laying Pipe can be done without interruption because all 3 tasks are planned to work at the same pace. Backfilling crews would also be studied to see if their production might be improved.

Flowline

Early versions of this technique were called 'Flowline' the most famous application being the construction of the Empire State Building, the rate of construction peaked at four and a half floors per week.






Location Based Scheduling

The modern version of Flowline is Location Based Scheduling (LBS). The illustration is from the Vico Location-Based Management System. LBS varies from LoB in that the amount of time allocated to each work location varies based on the volume of work required in that location. The objective remains same, synchronising the progress of different work crews to optimise the overall project delivery.



www.mosaicprojects.com.au





The location-based management system measures the progress of work crews as they flow through a building preserving the crew's productivity rate as they move from location to location. Each line represents one crew as they move through the building. The slope of the line marks their planned productivity rate and dotted lines that they are not operating optimally.

The number of data points needed to build and manage a LBS chart is a small fraction of the number needed to develop a CPM network to the same level of detail.

This White Paper is part of Mosaic's *Project Knowledge Index* to view and download a wide range of published papers and articles see: <u>http://www.mosaicprojects.com.au/PM-Knowledge_Index.html</u>

> For more information on scheduling and planning, visit Mosaic's scheduling home page at: <u>http://www.mosaicprojects.com.au/Planning.html</u>

